



...never slip again

# SlideProtect

## Package Contents



Textured coating 100ml



Degreaser 30ml



Spatula (2x)



Paint tray

(symbolic images)



Paint roller (2x) with bracket



Disposable gloves (2x)



Sandpaper

## Operating Instructions



SlideProtect is a high-adhesive and almost invisible anti-slip coating for virtually all smooth, non-absorbent floors. The 1-component system requires no additional mixing or thinning of the paint, the set is ready for immediate use. You will receive all necessary expendable items in this set (except paper towels / masking tape). The amount of paint is designed to coat e.g. one bathtub as well as one shower (up to 2sqm).

### Cleaning



Thoroughly clean the surface to be coated with a household lime and dirt remover. After that, remove the detergent completely from the surface by rinsing and then dry it.

### Degreasing



Use the included degreaser (ready to use) with a household cleaning cloth (or paper towel) for in-depth cleaning of the surface. To do this, put on the gloves and rub off the entire surface thoroughly with the cleaning cloth. Then dry completely with a lint-free cloth. Thereafter, the surface should be free of waxes, oils, soap residues and suchlike.

### Masking



It is generally recommended to mask the surface to be coated with adhesive tape. Do not coat any **silicone/acrylic joints**. For **showers and bathtubs**: apply an additional strip of tape from the drain to the opposite edge and attach the shower head / faucet to e.g. with a plastic bag to prevent dripping. *Please coat only the actual (horizontal) step areas! Be careful not to contaminate any fittings with paint residues.*

### Stirring



Thoroughly stir the textured coating in the original container with the enclosed spatula for at least 1 minute until no separated sediments are visible. Now pour the desired amount of coating (rule of thumb: 1/2 can be enough for a standard bath) into the roll-off tray and apply immediately then. Reseal remaining containers (for later use).

### Application



If necessary, remove any fluffs from the enclosed roller beforehand. Then apply the coating with the roller evenly overlapping onto the surface to be coated in a crosswise manner. Please apply thin, sparingly. This improves the effect!

### Completion



Now remove the tapes and let the coated surface harden for 24 hours. Afterwards, the area can be used as normal.

### Additional note

If you sense the surface to be „too rough“, especially in the bathtub, you may use the enclosed wet-sandpaper to additionally smooth the surface after hardening. The anti-slip effect will be retained.

### Special instructions for cleaning / disposal

The textured coating can not completely be removed from a used paint roller due to its high adhesion properties. Therefore, dispose used materials after use. Unintentional paint applications (such as splashes, e.g. on fittings) must be washed off immediately with plenty of water! After hardening, the coating will only be removable by grinding.



## BaronCoatings

Baron Coatings GmbH  
Kircheninsel 3  
DE 48599 Gronau  
Germany

[www.slideprotect.com](http://www.slideprotect.com)  
[info@baroncoatings.nl](mailto:info@baroncoatings.nl)  
[www.baroncoatings.nl](http://www.baroncoatings.nl)

Info-Telefon D/A/CH  
+49 (0)151 2011 8624